


## MODEL BKR MECHANICAL SETTING TOOL



Callout	3.593/ 3.937	4.312	5.375/ 5.687	6.312	7.125	8.125	9.000	9.437	10.437	12.00
A	3.062		3.672							
B	2.250									
C	2.375									
D	3.500		5.000	5.875	7.218	7.812	8.656	9.593	11.156	
E	6.250	6.959	8.374	9.260	10.600	11.194	12.038	12.960	14.535	
F	1.500									
G	3.375		4.875	5.750	7.093	7.687	8.531	9.468	11.031	
H	3.125		4.375							
J	3.745	4.312	5.375	6.312	7.125	8.125	9.000	9.437	10.437	12.000
K	2.750		4.125	4.593	5.593	6.593	7.593		10.093	
L	2.000		2.900							
M	1.320		1.990							
N	1.250		1.875							
P	1.320		1.990							
Q	1.320		1.990							
R	1.250		1.875							
S	1.062		1.562							
T	1.218		1.750							
W	1.156		1.687							
X	.750		1.250							
Y	45.031		47.640							
Z	58.250		61.062							